



SPA CARE

Your new spa will give you years of enjoyable pleasure. It will require a certain amount of maintenance and care to keep it clean. This guide will help you get started and take care of your spa. Keep it in a place that is easy to find for future reference. After you have completed the six steps below your spa will be ready to hop-in and enjoy.

Please take the time to test the water that you are using to fill your new spa with the test strips provided in the start-up kit. Make a note of these readings in the space provided in the back of your owners' manual. This will allow you know where your starting point is and will make the start-up go much smoother for you.

SAFETY TIPS

- Never heat your spa above 104°F.
- Do not drink alcohol while using your spa.
- Always shower before entering the spa.
- Limit your time in the spa to 15 minutes.
- Maintain a proper sanitizing level.
- Do not mix chemicals before adding to the water. Add each chemical separately.
- Always add chemicals to water, not water to chemicals.
- Always store chemicals according to the manufacturer's instructions and keep them out of the reach of children.

INITIAL SPA START UP

- STEP 1:** Your spa should be filled using a Pre-filter, see your sales representative. This Pre-filter will help remove many of the minerals existing in the water, which will make adjusting the water balance easier after a new fill. Never use more than 50% softened water when filling your spa.
- STEP 2:** During the initial filling of the spa, add a sequestering agent (Metal Gone) to combat suspended minerals in the water. Add the whole bottle as instructed on the label. Allow water to circulate and filter for at least 12 hours before adding any other chemicals.
- STEP 3:** Test water for pH and total Alkalinity using the test strips provided in the start-up kit. The pH should be 7.2 - 7.8 and the total Alkalinity 80-150 PPM. Calcium hardness levels should be maintained between 150 and 250 PPM (part per million).
- STEP 4:** Adjust pH and total Alkalinity utilizing the directions on the chemical bottles provided in the start up kit. (pH UP or pH Down)
- STEP 5:** It may be necessary to retest and add additional chemicals to get to the proper levels in Step 3. Once the total Alkalinity is in the 80- 150 range the pH will stabilize and stop fluctuating.
- STEP 6:** Add 2 tbsp. of concentrated sodium Dichlor-s-triazinetreone (Chlorinating Granules) per 500 gallons on initial start up to begin sanitizing the spa water. It is important not to add the chlorinating granules until the pH and total Alkalinity have been adjusted to their proper levels. Do not enter the spa when chlorine levels are above 5ppm.

Chlorinating Granules - Chlorine sanitizing agent

Oxidizer Shock - Oxidizing agent used to free up chlorine

pH UP - Raises pH and total Alkalinity

pH Down - Lowers pH and total Alkalinity

Foam Gone - Temporarily removes foam

Spa Brite - Helps combine small particles for clear water

Oil Gone - Enzyme that helps break down oils

Metal Gone - Sequesters metals suspended in the fill water

Filter Cleaner - Removes material from the filter media

Scale Defense - Keeps minerals in suspension

WEEKLY/MONTHLY MAINTENANCE SCHEDULE

BEFORE EACH USE	Check spa water with a test strip for sanitation levels and adjust accordingly to the proper levels.
AFTER EACH USE	Add 1 tbsp. of non-chlorine shock (Oxidizer Shock).
ONCE A WEEK	Add 2 tbsp. of a non-chlorine shock (Oxidizer Shock) to spa per 250 gallons.
3 TIMES A WEEK	Test water using chemical test strips. Adjust, alkalinity, pH, and sanitizer accordingly.
AS NEEDED	If water looks hazy, treat with 1 tbsp. of (Chlorinating Granules).
ONCE A MONTH	Soak your filter elements overnight in a container with (Filter Cleaner) and then rinse with clean water before re-inserting. The ECO PUR™ mineral element should never be cleaned in a filter cleaner. Just rinse with water.
EVERY 180 DAYS	Drain and refill your spa, replace with a new ECO PUR™ element, repeat start up procedure.

SPA WATER MAINTENANCE TROUBLE-SHOOTING GUIDE

PROBLEM	POSSIBLE CAUSES	HOW TO FIX IT
CHLORINE ODOR	-Excessive Chlorine	Shock water with Oxidizer Shock shock treatment
	-Low pH	Adjust pH if necessary
WATER ODOR	-Low levels of sanitizer	Adjust sanitizer level with Chlorinating Granules
	-pH out of range	Adjust pH level if necessary
CLOUDY WATER	-Bacteria or algae growth	Adjust sanitizer with Chlorinating Granules
	-Dirty filters or -inadequate filtration	Clean filters with Filter Cleaner and adjust filtration
	-Water chemistry not balanced	Adjust chemistry levels
	-Suspended particles or organic materials	Add Spa Brite
	-Old water	Change spa water
EYE / SKIN IRRITATION	-Unsanitary water	Shock spa with Oxidizer Shock
	-Free chlorine level above 5 PPM	Allow level to drop below 5 PPM
	-Poor sanitizer / pH levels	Adjust according to spa test strip results
FOAMING	-High levels of body, oils lotions, soap, etc.	Add small amount of Foam Gone and check water chemistry
SCUM DEPOSITS AT WATERLINE	-Body oils and dirt	Use Multi Purpose cleaner to clean spa surface and add Oil Gone to spa water
CHALKY, WHITE SCALE DEPOSITS	-Minerals in the water	Add Scale Defense

COVER

Clean underside of cover with clean water at every water change.

Make sure to keep the vinyl spa cover clean and treat with Cover Treat every 2-3 months.

Always leave cover open for at least 10 minutes after adding Chlorine to the spa water.

RECOMMENDED LEVELS OF CHEMICAL

Chlorine 1.0 - 3.0 PPM

pH 7.2 - 7.8

Total Alkalinity 80 - 150 PPM

Calcium Hardness 180 - 250 PPM

Do not enter the spa when chlorine levels are above 5ppm.